



Water Filtration Products

INSTALLATION AND OPERATING INSTRUCTIONS

CFSM1254 WATER SOFTENER

**Installer: Please leave this manual with owner/operator.
Owner/Operator: Please retain for operation and future
maintenance instructions.**

SAFETY INFORMATION

Read, understand, and follow all safety information contained in these instructions prior to installation and use of the CFSM1254 Water Softener. Retain these instructions for future reference. Failure to follow installation, operation and maintenance instructions may result in property damage and will void warranty.

Intended use:

The CFSM1254 Water Softener is intended for use in softening water and has not been evaluated for other uses. The system must be installed indoors near the point of entry of a water line, and be installed by qualified professional installers according to these installation instructions.

EXPLANATION OF SIGNAL WORD CONSEQUENCES



WARNING

Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury and/or property damage.

CAUTION

Indicates a potentially hazardous situation, which, if not avoided, may result in property damage.



WARNING

To reduce the risk associated with choking:

- **Do not** allow children under 3 years of age to have access to small parts during the installation of this product.

To reduce the risk associated with ingestion of contaminants:

- **Do not** use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

To reduce the risk of physical injury:

- Shut off inlet water supply and depressurize system as shown in manual prior to service.

To reduce the risk associated with a hazardous voltage:

- If the electrical system requires use of the cold water system as an electrical safety ground, a jumper must be used to ensure a sufficient ground connection across the filter installation piping — refer installation to qualified personnel.
- **Do not** use the system if the power cord is damaged — contact qualified service personnel for repair.

To reduce the risk associated with back strain due to the heavy weight of the various system components:

- Follow safe lifting procedures.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- **Read and follow** Use instructions before installation and use of this water treatment system.
- Installation and use **MUST** comply with existing state or local plumbing codes.
- **Protect from freezing**, relieve pressure and drain system when temperatures are expected to drop below 33°F (0.6°C).
- **Do not** install on hot water supply lines. The maximum operating water temperature of this filter system is 110°F (43.3°C).
- **Do not** install systems in areas where ambient temperatures may go above 110°F (43.3°C) or below 40°F (4.4°C).
- **Do not** install if water pressure exceeds 100 psi. If your water pressure exceeds 80 psi (552 kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- **Do not** install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.
- **Do not** use a torch or other high temperature sources near filter system, cartridges, plastic fittings or plastic plumbing.
- On plastic fittings, never use pipe sealant or pipe dope. **Use PTFE thread tape only**, pipe dope properties may deteriorate plastic.
- Take care when using pliers or pipe wrenches to tighten plastic fittings, as damage may occur if over tightening occurs.
- **Do not** install in direct sunlight or outdoors.
- Mount system in such a position as to prevent it from being struck by other items used in the area of installation.
- Ensure all tubing and fittings are secure and free of leaks.
- **SHUT OFF FUEL OR ELECTRIC POWER SUPPLY TO WATER HEATER** after water is shut off.
- **Do not** install system where water lines could be subjected to vacuum conditions without appropriate measures for vacuum prevention.
- **Do not** apply heat to any fitting connected to Bypass or Control Valve as damage may result to internal parts or connecting adapters.
- Install on a flat/level surface. It is also advisable to sweep the floor to eliminate objects that could pierce the brine tank.

To reduce the risk associated with property damage due to plugged water lines:

- Pay particular attention to correct orientation of control valve. Water flow should match arrow on control valve. The Inlet and Outlet of other water treatment equipment products will vary depending on the control valve brand used.

TABLE OF CONTENTS

<u>SECTION</u>	<u>DESCRIPTION</u>
1	BEFORE INSTALLATION
2	INSTALLATION
3	CONTROL VALVE PROGRAMMING AND REGENERATION
4	MAINTENANCE
5	TROUBLESHOOTING AND SERVICE INSTRUCTIONS
6	SPECIFICATIONS & OPERATING DATA
7	PARTS
	LIMITED WARRANTY

SECTION 1: BEFORE INSTALLATION

When properly installed, operated, and maintained, your new softener will provide many years of dependable service. Before starting the installation please read this manual all the way through for an overview, and then follow the installation in proper sequence. **Failure to follow instructions will void warranty.**

Inspecting And Handling Your Softener:

Inspect the equipment for shipping damage. If damaged, notify the transportation company and request a damage inspection.

Handle the equipment with care. Damage can result if dropped or if the brine tank is set on sharp, uneven projections on the floor. When handling, do not turn the water softener unit upside down.

Make Sure Your Water Has Been Thoroughly Tested:

An analysis of your water should be made prior to the selection of your water conditioning equipment. Your dealer will generally perform this service for you, and may send a sample to the factory for analysis and recommendations. Enter your analysis below for your permanent record.

Analysis of Your Water:

Hardness _____ gpg	Tannins (Humic Acid) _____ ppm
Iron (Fe) _____ ppm	Hydrogen Sulfide (H ₂ S) _____ ppm
Manganese (Mn) _____ ppm	Other _____ ppm
pH _____ ppm	Other _____ ppm

IMPORTANT NOTES

Hydrogen sulfide (H₂S) must be tested for at the well site. For accuracy, the sample must be drawn with the pump RUNNING, and the test be completed within ONE minute after the sample is drawn.

Softeners are designed to reduce hardness but can handle reasonable amounts of soluble iron if consideration is given to content when selecting model and regeneration settings. To treat sulfur (hydrogen sulfide), bacterial iron, precipitated iron or very high levels of soluble iron requires special equipment in addition to a water softener. For best results, a Chem-Free Iron Reduction System is recommended for use on waters containing more than 2 ppm of iron.

Check Your Pumping Rate and Water Pressure:

Two water system conditions must be checked carefully to avoid unsatisfactory operation or equipment damage:

- 1) MINIMUM water pressure required at the water softener inlet is 20 psi (1.4 bar). IF WATER PRESSURE IS OVER 80 psi (552 kPa), A PRESSURE REDUCING VALVE MUST BE INSTALLED IN THE WATER SUPPLY LINE AHEAD OF THE WATER SOFTENER.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- Do not install if water pressure exceeds 100 psi. If your water pressure exceeds 80 psi (552 kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.

NOTE: If you have a municipal or a community water supply and daytime water pressure is 85 psi or more, nighttime pressure may exceed 100 psi. Call your local water department or plant operator to obtain pressure readings. If you have a private well, the gauge on the pressure tank will indicate the high and low system pressure. Record your water pressure data below:

Water Pressure:

Low _____ psi

High _____ psi

CAUTION

To reduce the risk associated with property damage due to water leakage:

- Do not install system where water lines could be subjected to vacuum conditions without appropriate measures for vacuum prevention.

The installer should take appropriate measures if there is the possibility a vacuum may occur. This would include the installation of an appropriate device in the supply line to the system, i.e., a vacuum breaker or backflow prevention device. Vacuum damage voids the factory warranty.

- 2) The pumping rate of your well must be sufficient for satisfactory operation and BACKWASHING of the water softener. (See SPECIFICATIONS AND OPERATING DATA, Section 6)

Locate Water Conditioning Equipment Correctly:

Select the location of your water softener with care. Various conditions which contribute to proper location are as follows:

- 1) Locate as close as possible to water supply source.
- 2) Locate as close as possible to a drain.
- 3) Locate in correct relationship to other water conditioning equipment (Figure 1).
- 4) Locate the softener in the supply line BEFORE the water heater. Temperatures above 100°F (38°C) will damage the softener and void the factory warranty.
- 5) DO NOT install the softener in a location where freezing temperatures occur. Freezing may cause permanent damage and will also void the factory warranty.
- 6) Allow sufficient space around the installation for easy servicing.
- 7) Provide a non-switched 110V, 60Hz (220V, 50Hz for specified systems) power source for the control valve.

WARNING

To reduce the risk associated with ingestion of contaminants:

- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- Protect from freezing, relieve pressure and drain system when temperatures are expected to drop below 33°F (0.6°C).
- Do not install on hot water supply lines. The maximum operating water temperature of this filter system is 110°F (43.3°C).
- Do not install systems in areas where ambient temperatures may go above 110°F (43.3°C) or below 40°F (4.4°C).

Facts to Remember While Planning Your Installation:

- 1) All installation procedures **MUST** conform to local and state plumbing codes.
- 2) Remember that the water softener **INLET** is attached to the pipe that supplies water (i.e. runs to the pump) and the **OUTLET** is the line that runs toward the water heater.

CAUTION

To reduce the risk associated with property damage due to plugged water lines:

- Pay particular attention to correct orientation of control valve. Water flow should match arrow on control valve. The Inlet and Outlet of other water treatment equipment products will vary depending on the control valve brand used.

- 3) Before commencing the installation it is advisable to study the existing piping system and to determine the size, number and type of fittings required.

WARNING

To reduce the risk associated with a hazardous voltage:


- If the electrical system requires use of the cold water system as an electrical safety ground, a jumper must be used to ensure a sufficient ground connection across the filter installation piping — refer installation to qualified personnel.

- 4) It is also advisable to sweep the floor to eliminate objects that could pierce the brine tank.


IMPORTANT NOTE

Sodium Information: Water softeners utilizing sodium chloride for regeneration add sodium to the water softened water. Persons who are on sodium restricted diets should consider the added sodium as part of their overall sodium intake. As a reference as to how much sodium is added to softened water consider the following. For each grain per gallon of water hardness that is exchanged from the water supply, 7.5 milligrams per liter of sodium will be added to the softened water. e.g. 10 grains per gallon (gpg) exchanged will add 75 milligrams of sodium to the softened water.

SECTION 2: INSTALLATION



STANDARD WELL INSTALLATION



PUBLIC WATER SUPPLY INSTALLATION

Figure 1. Typical Installation

CAUTION

To reduce the risk associated with property damage due to water leakage:

- **Read and follow** Use instructions before installation and use of this water treatment system.
- Installation and use **MUST** comply with existing state or local plumbing codes.

To reduce the risk associated with property damage due to plugged water lines:

- Pay particular attention to correct orientation of control valve. Water flow should match arrow on control valve. The Inlet and Outlet of other water treatment equipment products will vary depending on the control valve brand used.

SECTION 2: INSTALLATION

- Step 1) Remove the unit from the shipping box and remove all packaging. Ensure no freight damage has occurred since shipment from our manufacturing facility. Locate the parts package and install the bypass and adapter fittings on the control valve to facilitate the connection to the customer's water supply.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- On plastic fittings, never use pipe sealant or pipe dope. **Use PTFE thread tape only**, pipe dope properties may deteriorate plastic;
- Take care when using pliers or pipe wrenches to tighten plastic fittings, as damage may occur if over tightening occurs.

- Step 2) Verify all packaging materials have been removed from the brine tank. On all units, legs rest on bottom of the brine tank.

- Step 3) Shut off all water at main supply valve. On a private well system, turn off power to the pump and drain pressure tank. Make certain pressure is relieved from complete system by opening nearest faucet to drain system.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- **SHUT OFF FUEL OR ELECTRIC POWER SUPPLY TO WATER HEATER** after water is shut off.

- Step 4) Cut main supply line as required to fit plumbing to INLET and OUTLET of unit.

- Step 5) Attach plumbing. **DO NOT** apply heat to any fitting connected to BYPASS or CONTROL VALVE as damage may result to internal parts or connecting adapters. **MAKE CERTAIN WATER FLOW ENTERS THROUGH INLET AND DISCHARGES THROUGH OUTLET.**

⚠ WARNING

To reduce the risk associated with a hazardous voltage:

- If the home electrical system requires use of the cold water system as an electrical safety ground, a jumper must be used to ensure a sufficient ground connection across the filter installation piping — refer installation to qualified personnel.

- Step 6) The controls allow for either a 3/4" NPT connection or 5/8" poly tubing for use as a drain line connection.

CAUTION

To reduce the risk associated with property damage due to water leakage:

- On plastic fittings, never use pipe sealant or pipe dope. **Use PTFE thread tape only**, pipe dope properties may deteriorate plastic;
- Take care when using pliers or pipe wrenches to tighten plastic fittings, as damage may occur if over tightening occurs.





Figure 2. SOFTENER AND BRINE TANK ASSEMBLY, TOP VIEW

Step 7) Attach DRAIN LINE to DRAIN LINE FITTING. To prevent back pressure from reducing flow rate below minimum required for backwash, DRAIN LINE MUST be sized according to run length and relative height. Be careful not to bend flexible drain tubing sharply enough to cause “kinking” (if kinking occurs DRAIN LINE MUST BE REPLACED). Typical examples of proper DRAIN LINE diameters are:

- 1) 1/2" ID up to 15 ft. when discharge is lower than INLET.
- 2) 5/8" ID up to 15 ft. when discharge is slightly higher than the INLET.
- 3) 3/4" ID when drain is 25 ft. away and/or drain is installed overhead.

Some areas prohibit the use of flexible drain lines. Check with local code officials prior to installation.

Step 8) Position DRAIN LINE over drain and secure firmly. To prevent backsiphoning of sewer water, provide an air-gap of at least 2" or 2 pipe diameters between end of drain hose and drain (Figure 3). DO NOT raise DRAIN LINE more than 10 ft. above floor.




Step 9) Connect one end of the 3/8" black Polyethylene tubing to the brine fitting located on the left side of the CONTROL VALVE. Connect the other end to the SAFETY BRINE VALVE ELBOW inside of the brine well in the brine tank. To do so remove the retaining clip from the brine line fitting on the control valve. The retaining clip is holding a plastic insert sleeve and needs to be inserted into the polyethylene tubing before installing the tubing into the fitting elbow and hand tighten only. **CAUTION: Do not use pliers or wrenches to tighten as damage may occur and will void the manufacturer's warranty.**

Step 10) Install OVERFLOW LINE to brine tank OVERFLOW FITTING (Figure 2). Discharge of line must be lower than OVERFLOW FITTING. DO NOT INTERCONNECT OVERFLOW LINE WITH VALVE DRAIN LINE.

Step 11) Make certain BYPASS VALVE INLET and OUTLET KNOBS ARE IN “BYPASS” position. After all plumbing connections have been completed, open main water shut-off valve or restore power to well pump. Check for leaks and correct as necessary.

Step 12) Plug CONTROL VALVE POWER CORD into 120v/60Hz, non-switched power source. Manually stage control to BACKWASH POSITION and then unplug power cord to prevent the unit from advancing automatically.

Step 13) Partially open INLET knob on bypass valve (Figure 4). This will allow the unit to fill slowly from the bottom up, reducing air entrapment. Allow unit to fill slowly, failure to do so could result in loss of resin to the drain. Once a steady stream of water, no air, is flowing to drain the inlet and outlet knobs on the bypass can be fully opened.




Step 14) Plug the power cord back into the power source. Press the REGEN button and wait for the valve to advance to the next regeneration position. Repeat the process until the valve is in Service Position (Time will be on the display).

Step 15) Refer to **Section 3: Regeneration Instructions**, on how to set control valve for proper set up and regeneration settings.

NOTE: Regeneration settings for the control valve are factory preset. The control valve design permits adjustment of the salt setting. This adjustment may be necessary when unusual operating conditions exist, such as high concentrations of iron, manganese or hardness and/or high flow rates or daily water consumption.

SPECIAL SERVICE INSTRUCTIONS:

Under normal circumstances removal of valve should not be required. However, if it must be removed, can be done by disassembling the quick release clamp, and latch. Pressure should be relieved before attempting any disassembly. Upon reassembly, all o-rings should be lubricated with silicone grease. Reassemble clamp as shown in Figure 5. MAKE SURE ARROWS ON LATCH SIDE OF CLAMP ARE ALIGNED.



SECTION 3: CONTROL VALVE PROGRAMMING AND REGENERATION

Grains Capacity/lb NaCl		6,000 to 3,000
Lbs NaCl/cu ft resin ²		Less than 7.5
Cycle Time in Minutes	Backwash Normal	8
	Regenerate	60
	Backwash Normal	10
	Rinse	8
	Total ³	86



WS1 & WS 1.25 Downflow Regenerant Refill After Rinse	
1st Cycle	Backwash
2nd Cycle	Regenerate
3rd Cycle	Backwash
4th Cycle	Rinse
5th Cycle	Fill Dissolve
6th Cycle	Service



Installer Display Settings

(Step 1) Press NEXT and ▲ simultaneously for 3 seconds.

(Step 2) Hardness: Set the amount of hardness in grains of hardness as calcium carbonate per gallon using the ▼ or ▲ buttons. The default is 20 with value ranging from 1 to 150 in 1 grain increments. Note: The grains per gallon can be increased if soluble iron needs to be reduced. Press NEXT to go to Step 3. Press REGEN to exit Installer Display Settings.

(Step 3) Day Override: Day Override sets the number of days between regenerations and sets the maximum number of days between regenerations. If value is set as a number (allowable range from 1 to 28) a regeneration initiation will be called for on that day even if sufficient number of gallons were not used to call for a regeneration. Set Day Override using ▼ or ▲ buttons.

- number of days between regeneration (1 to 28); or “OFF”.

Press NEXT to go to Step 4. Press REGEN to return to previous step.

(Step 4) Next Regeneration Time (hour): Set the hour of day for regeneration using ▲ or ▼ buttons. AM/PM toggles after 12. The default time is 2:00 a.m. Press NEXT to go to Step 5. Press REGEN to return to previous step.

(Step 5) Next Regeneration Time (minutes): Set the minutes of day for regeneration using ▲ or ▼ buttons. Press NEXT to exit Installer Display Settings. Press REGEN to return to previous step.


To initiate a manual regeneration immediately, press and hold the “REGEN” button for three seconds. The system will begin to regeneration immediately. The control valve may be stepped through the various regeneration cycles by pressing the “REGEN” button.

Power Lost

If power goes out for less than two hours, the system will automatically reset itself. If an extended power outage occurs, the time of day will flash on and off which indicated the time of day should be reset. The system will remember the rest.

Error Message

If the word “error” and a number are alternately flashing on the display contact the “Technical Support Services Department” at CUNO Incorporated, phone number 1-866-693-2543 for help. This indicates that the valve was not able to function properly.



RETURN TO
NORMAL MODE

Diagnostics

(Step 1) Press ▼ or ▲ simultaneously for 3 seconds. If screen in step does not appear in 5 seconds the lock on the valve is activated. To unlock press, ▼, NEXT, ▲, and SET CLOCK in sequence, then press NEXT and ▼ simultaneously for 3 seconds.

(Step 2) Days, since last regeneration: This display shows the days since the last regeneration occurred. Press the NEXT button. Press REGEN to exit Diagnostics.

(Step 3) Gallons, since last regeneration: This display shows the number of gallons that have been treated since the last regeneration. This display will equal zero if a water meter is not installed. Press the NEXT button. Press REGEN to return to previous step.

(Step 4) Gallons, reserve capacity used for last 7 days: This display shows 0 day (for today) and flashes the reserve capacity. Pressing the ▲ button show day 1 (which would be yesterday) and flashes the reserve capacity used. Pressing the ▲ button again will show day

2 (the day before yesterday) and reserve capacity. Keep pressing the ▲ button to show the gallons for days 3, 4, 5 and 6. The ▼ button can be pressed to move backwards in the day series. Press the NEXT button at any time. Press REGEN to return to previous step.

(Step 5) Gallons, 63 day usage history: This display shows day 1 (for yesterday) and flashes the number of gallons treated yesterday. Pressing the ▲ button will show day 2 (which would be the day before yesterday) and flashes the number of gallons treated on that day. Continue to press the ▲ button to show the maximum number of gallons treated for the last 63 days. This display will show dashes if a water meter is not installed. Press the NEXT button at any time. Press REGEN to return to previous step.


(Step 6) Flow rate, current: Turn the water on at one or more taps in the building. The flow rate in gallons per minute will be displayed. If flow stops the value will fall to zero in a few seconds. This display will equal zero if a water meter is not installed. Press the NEXT button. Press REGEN to return to previous step.

(Step 7) Flow rate, maximum last seven days: The maximum flow rate in gallons per minute that occurred in the last seven days will be displayed. This display will equal zero if a water meter is not installed. Press the NEXT button. Press REGEN to return to previous step.

(Step 8) Gallons, total used since last reset: The total number of gallons used since last reset will be displayed. This display will equal zero if a water meter is not installed. Press the NEXT button. Press REGEN to return to previous step.

(Step 9) Days, total number since last reset: The total number of days the control valve has been in service since last reset will be displayed. Press the NEXT button. Press REGEN to return to previous step.

(Step 10) Regenerations, total number since last reset: The total number of regenerations that have occurred since last reset will be displayed. Press the NEXT button to exit Diagnostics. Press REGEN to return to previous step. To lock settings press ▼, NEXT, ▲, and SET CLOCK in sequence.



Valve History

(Step 1) Press or simultaneously for 3 seconds and release. Then press and simultaneously and release. If screen, to the left, does not appear is 5 seconds the lock on the valve is activated. To unlock press , NEXT, and SET CLOCK in sequence, then press and . Then press and simultaneously and release.

(Step 2) Software Version: This display shows the software version of the valve. Press the NEXT button to go to the next step or press REGEN to exit Valve History.

(Step 3) Flow rate, maximum since startup: This display shows the maximum flow rate in gallons per minute that has occurred since startup. This display will equal zero if a water meter is not functioning. Press the NEXT button to go to the next step. Press REGEN to return to previous step.

(Step 4) Gallons, total used since start-up: This display shows the total gallons. This display shows the total days since start-up. Press the NEXT button to go to the next step. Press REGEN to return to previous step.

(Step 5) Days, total since start-up: This display shows the total days since start-up. Press the NEXT button to go to the next step. Press REGEN to return to previous step.


(Step 6) Regenerations, total number since start-up: This display shows the total number of regenerations that have occurred since start-up. Press the NEXT button to go to the next step. Press REGEN to return previous step.

(Step 7) Error, number of occurrences since start-up: This display shows E and the total number of errors that have occurred since start-up. Press the NEXT button to exit Valve History. Press REGEN to return to previous step. To lock settings press , NEXT, and SET CLOCK in sequence.

User Display Settings

General Operation

When the system is operating, one of two displays will be shown. Pressing NEXT will alternate between the displays. One of the displays is always the current time of day. The second display is one of the following: days remaining or gallons remaining. Days remaining is the number of days left before the system goes through a regeneration cycle. Capacity remaining is the number of gallons that will be treated before the system goes through a regeneration cycle. The user can scroll between the displays as desired.



If the system has called for a regeneration that will occur at the preset time of regeneration, the words “REGEN TODAY” will appear on the display.

When water is being treated (i.e. water is flowing through the system) the word “SOFTENING” flashes on the display if a water meter is installed.

Regeneration Mode


Typically a system is set to regenerate at a time of low water usage. An example of a time with low water usage is when members of a household are asleep. If there is a demand for water when the system is regenerating, untreated water will be used.



When the system begins to regenerate, the display will change to include information about the step of the regeneration process and the time remaining for that step to be completed. The system runs through the steps automatically and will reset itself to help provide treated water when the regeneration has been completed.

Manual Regeneration

Sometimes there is a need to regenerate the system sooner than when the system calls for it, usually referred to as manual regeneration. There may be a period of heavy water usage because of guests or a heavy laundry day.



To initiate a manual regeneration at the present delayed regeneration time, press and release “REGEN”. The words “REGEN TODAY” will flash on the display to indicate that the system will regenerate at the preset delayed regeneration time.

NOTE: If you pressed the “REGEN” button in error, pressing the button again will cancel the request.

To initiate a manual regeneration immediately, press and hold the “REGEN” button for 3 seconds. The system will begin to regenerate immediately. The request cannot be cancelled.

NOTE: For softeners, if brine tank does not contain salt, fill with salt and wait at least two hours before regenerating.


Set Time of Day

The user can also set the time of day. Time should only need to be set after extended power outages or when daylight saving time begins or ends. If an extended power outage occurs, the time of day will flash on and off which indicates the time of day should be reset.

Step 1 - Press SET CLOCK.

Step 2 - Current Time (hour): Set the hour of the day using ▲ or ▼ button. AM/PM toggles after 12. Press NEXT to go to Step 3.

Step 3 - Current Time (minutes): Set the minutes of the day using ▲ or ▼ buttons. Press NEXT to exit Set Clock. Press “REGEN” to return to previous step.



SECTION 4: MAINTENANCE

Replenishment of Salt Supply:

The salt storage capacity of the brine tank is approximately 135 lbs. (61 kg). During each regeneration a specific amount of salt is consumed, thus requiring its periodic replenishment (the frequency and salt dosage level is dependent on the regeneration schedule). Always replenish salt before the supply is exhausted for a continuous supply of softened water.

Type of Salt to Use:

Any type of water softener salt may be used. There are advantages and disadvantages to every type of salt. Please ask your local dealer for his advice. Your unit is designed to compensate for the disadvantages. However the use of block salt is not encouraged due to its possible problems in making enough brine for regeneration purposes.

Brine Tank Clean-Out:

To prevent service problems the brine tank should be emptied and flushed out with a garden hose when dirt and other insolubles accumulate.

Steps to follow:

- (1) Disconnect brine line at either end.
- (2) Turn brine tank upside down and discard old salt.
- (3) Rinse out with a garden hose.
- (4) Reconnect brine line.
- (5) Before loading salt, using a pail or garden hose, add enough water to the brine tank to cover the salt grid lower shelf on 15" x 15" x 34" brine tank at least one (1) inch in depth. Then add initial salt to brine tank and add one (1) cup of unscented laundry bleach to the brine well.
- (6) Perform approximately once a year if rock salt is used; with other types of salt, approximately once every other year.

Preventing Iron-Fouling of Mineral Bed:

If iron is present in the water supply, the softener mineral bed will eventually become iron-fouled, resulting in reduced softening capacity and rust-stained fixtures. Mixing one to two ounces of IRON-X Mineral Cleaner with every 80 lbs. of salt added to brine tank will help minimize these problems from occurring. IRON-X is available from your dealer.

Periodically Check Time of Day Setting:

Power outages will cause "TIME OF DAY" setting to become incorrect. To correct, refer to Section 4.

Malfunction of Unit:

Your water softener, under normal conditions, should provide years of virtually trouble-free service; however, since it is a mechanical device, it can malfunction. (Refer to Section 5, SERVICE INSTRUCTIONS, if necessary).

Change of Operating Conditions:

Should your family size, your water usage habits, or your water quality change, the regeneration program settings may have to be adjusted. Consult your dealer if any of the above occur.

Special Service Instructions:

Under normal circumstances removal of valve should not be required. However, if it must be removed, it can be done by disassembling the quick release clamp, and latch. Pressure should be relieved before attempting any disassembly. Upon reassembly, all o-rings should be lubricated with silicone grease. Reassemble clamp as shown in Figure 5. MAKE SURE ARROWS ON LATCH SIDE OF CLAMP ARE ALIGNED.




Figure 6. CLAMP ASSEMBLY

SECTION 5: CONTROL VALVE TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
1. Timer does not display time of day	A. AC Adapter unplugged	A. Connect power
	B. No electric power at outlet	B. Repair outlet or use working outlet
	C. Problem with AC Adapter	C. Replace AC Adapter
	D. Problem with PC Board	D. Replace PC Board
2. Timer does not display correct time of day	A. Switched outlet	A. Use uninterrupted outlet
	B. Power outage	B. Reset time of day
	C. Problem with PC board	C. Replace PC board
3. No softening/filtering display when water is flowing	A. Bypass valve in bypass position	A. Put bypass valve in service position
	B. Meter connection disconnected	B. Connect meter to PC board
	C. Restricted/stalled meter turbine	C. Remove meter and check for rotation or foreign material
	D. Problem with meter	D. Replace meter
	E. Problem with PC board	E. Replace PC board
4. Control Valve regenerates at wrong time of day	A. Power outages	A. Reset control valve to correct time of day
	B. Time of day not set correctly	B. Reset to correct time of day
	C. Time of regeneration incorrect	C. Reset regeneration time
5. ERROR followed by code number Error Code 1001 - Unable to recognize start of regeneration Error Code 1002 - Unexpected stall Error Code 1003 - Motor ran too long, timed out trying to reach next cycle position Error Code 1004 - Motor ran too long, timed out trying to reach home position If other Error Codes display, contact the factory	A. Control valve has just been serviced or unplug power source jack (black wire) and plug back in to reset control valve.	A. Press NEXT and REGEN for 3 seconds
	B. Foreign matter is lodged in control valve	B. Check piston and spacer stack assembly
	C. High drive forces on piston	C. Replace piston(s) and spacer stack assembly
	D. Control valve piston not in home position seconds	D. Press NEXT and REGEN for 3 seconds or unplug power source jack (black wire) and plug back in to reset control valve
	E. Motor not inserted fully to engage pinion, motor wires broken or disconnected, motor failure	E. Check motor and wiring. Replace motor if necessary
	F. Drive gear label dirty or damaged, missing or broken gear	F. Replace or clean drive gear
	G. Drive bracket incorrectly aligned to back plate	G. Reseat drive bracket properly
	H. PC board is damaged or problematic	H. Replace PC board
	I. PC board incorrectly aligned to drive bracket	I. Ensure PC board is correctly snapped on to drive bracket
6. Control valve stalled in regeneration	A. Motor not operating	A. Replace motor
	B. No electric power at outlet	B. Repair outlet or use working outlet
	C. Problem with AC Adapter	C. Replace AC Adapter
	D. Problem with PC board	D. Replace PC board
	E. Broken drive gear or drive cap assembly	E. Replace drive gear or drive cap assembly
	F. Broken piston retainer	F. Replace drive cap assembly
	G. Broken main or regenerant piston	G. Replace main or regenerant piston
7. Control valve does not regenerate automatically when "REGEN" button is depressed and held	A. AC Adapter unplugged	A. Connect AC Adapter
	B. No electric power at outlet	B. Repair outlet or use working outlet
	C. Broken drive gear or drive cap assembly	C. Replace drive gear or drive cap assembly
	D. Problem with PC board	D. Replace PC board
8. Control valve does not regenerate automatically but does when "REGEN" button is depressed	A. Bypass valve in bypass position	A. Put bypass valve in normal operating position
	B. Meter connection disconnected	B. Connect meter to PC board
	C. Restricted/stalled meter turbine	C. Remove meter and check for rotation or foreign matter
	D. Problem with meter	D. Replace meter
	E. Problem with PC board	E. Replace PC board
	F. Set-up error	F. Check control valve set-up procedure
9. Time of day flashes on and off	A. Power has been out more than two hours, the AC Adapter was unplugged and then plugged back into the wall outlet, the AC Adapter plug was unplugged and then plugged back into the board or the NEXT and REGEN buttons were pressed to reset the valve	A. Reset the time of day

SECTION 5: CONTROL VALVE SERVICE INSTRUCTIONS

Drive Assembly:

Remove the valve cover to access the drive assembly.

IMPORTANT NOTE: Disconnect the power source plug (black wire) from the PC board prior to disconnecting the motor or water meter plugs from the PC board. The power source plug connects to the four-pin jack. The motor plug connects to the two-pin jack on the left-hand side of the PC board. The water meter plug (grey wire) connects to the three-pin jack on the far right-hand side of the PC board.

The PC board can be removed separately from the drive bracket but it is not recommended. Do not attempt to remove the display panel from the PC board. Handle the board by the edges. To remove the PC board from the drive bracket, unplug the power, water meter and motor plugs from the PC board. Lift the middle latch along the top of the drive bracket while pulling outward on the top of the PC board. The drive bracket has two plastic pins that fit into the holes on the lower edges of the PC board. Once the PC board is tilted about 45° from the drive bracket it can be lifted off of these pins. To reinstall the PC board, position the lower edge of the PC board so that the holes in the PC board line up with the plastic pins. Push the top of the PC board towards the valve until it snaps under the middle latch, weave the power and water meter wires into the holders and reconnect the motor, water meter and power plugs.

The drive bracket must be removed to access the drive cap assembly and pistons or the drive cap gear cover. It is not necessary to remove the PC board from the drive bracket to remove the drive bracket. To remove the drive bracket, start by removing the plugs for the power source and the water meter. Unweave the wires from the side holders. Two tabs on the top of the drive back plate hold the drive bracket in place. Simultaneously lift the two tabs and gently ease the top of the drive bracket forward. The lower edge of the drive bracket has two notches that rest on the back plate. Lift up and outward on the drive bracket to disengage the notches.

To reassemble, seat the bottom of the drive bracket so the notches are engaged at the bottom of the drive back plate. Push the top of the drive bracket toward the two latches. The drive bracket may have to be lifted slightly to let the threaded piston rod pass through the hole in the drive bracket. Maintain a slight engaging force on top of the drive bracket while deflecting the bracket slightly to the left by pressing on the side of the upper right corner. This helps the drive gears mesh with the drive cap assembly. The drive bracket is properly seated when it snaps under the latches on the drive back plate. If resistance is felt before latching, then notches are not fully engaged, the piston rod is not in the hole, the wires are jammed between the drive bracket and drive back plate, or the gear is not engaging the drive cap assembly. To inspect the drive gears, the drive gear cover needs to be removed. Before trying to remove the gear cover, the drive bracket must be removed from the drive back plate. (Refer to the proceeding instructions regarding removing the drive bracket from the drive back plate. The drive gear cover can be removed from the drive bracket without removing the motor or the PC board.) The drive gear cover is held in place on the drive bracket by three clips. The largest of the three clips is always orientated to the bottom of the drive bracket. With the PC board facing up, push in and down on the large clip on the drive gear cover. Handle the cover and the gears carefully so that the gears do not fall off of the pegs in the cover.

Replace broken or damaged drive gears. Do not lubricate any of the gears. Avoid getting any foreign matter on the reflective coating because dirt or oils may interfere with pulse counting.

The drive gear cover only fits on one way, with the large clip orientated towards the bottom. If all three clips are outside of the gear shroud on the drive bracket and the drive gear cover slips easily into place.

The drive bracket does not need to be removed from the drive plate if the motor needs to be removed. To remove the motor, disconnect the power and motor plugs from the jacks on the PC board. Move the spring clip loop to the right and hold. Rotate the motor at least a 1/4 turn in either direction so the wires are vertical (up & down) before gently pulling on the wire connectors to remove the motor. Pulling directly on the wires without rotating the motor may break the wires off the motor.

Replace the motor if necessary. Do not lubricate the motor or the gears. To reinstall the motor, move the spring clip loop to the right and hold. Gently turn the motor while inserting so that the gear on the motor meshes with the gears under the drive gear cover. Release the spring clip loop and continue to rotate the motor until the wires are horizontal and the motor housing engages the small plastic bulge inside the drive bracket motor retainer. Reconnect the motor plug to the two-pronged jack on the lower left hand side of the PC board. If the motor will not easily engage with the drive gears when reinstalling, lift and slightly rotate the motor before reinserting. Reconnect the power.

Replace the valve cover. After completing any valve maintenance, press and hold NEXT and REGEN buttons for 3 seconds or unplug power source jack (black wire) and plug back in. This resets the electronics and establishes the service piston position. The display should flash all wording, then flash the software version (e.g. 181) and then reset the valve to the service position.


Drive Cap Assembly, Main Piston and Regenerant Piston:

The drive assembly must be removed to access the drive cap assembly. The drive cap assembly must be removed access the piston(s). The drive cap assembly is threaded into the control valve body and seals with an o-ring. To remove the drive cap assembly use the special plastic wrench or insert a ¼" to ½" flat blade screwdriver into one of the slots around the top 2" of the drive cap assembly so it engages the notches molded into the drive back plate around 2" or the piston cavity. See Figure 7. The notches are visible through the holes. Lever the screwdriver so the drive cap assembly turns to the left. Once loosened, unscrew the drive cap assembly by hand and pull straight out. The drive cap assembly contains the drive cap, the main drive gear, drive cap spline, piston rod and various other parts that should not be dissembled in the field. The only replaceable part on the drive cap assembly is the o-ring. Attached to the drive cap assembly is the main piston and a regenerant piston.

The regenerant piston (the small diameter one behind the main piston) is removed form the main piston by pressing sideways and unsnapping if from its latch. Chemically clean in dilute sodium or vinegar, or replace the regenerant piston if needed. To remove the main piston fully extend the piston rod and then unsnap the main piston from its latch by pressing on the side with the number. Chemically clean in dilute sodium bisulfite or vinegar, or replace the main piston.

Reattach the main piston to the drive cap assembly. Reattach the regenerant piston (if needed) to the main piston. Do not lubricate the piston rod, main piston or regenerant piston. Lubricant will adversely affect the clear lip seals. Reinsert the drive cap assembly and piston into the spacer stack assembly and hand tighten the drive cap assembly. Continue to tighten the drive cap assembly using a screwdriver as a ratchet until the black o-ring on the spacer stack assembly is no longer visible through the drain port. Excessive force can break the notches molded into the drive back plate. Make certain that the main drive gear still turns freely.

The exact position is not important as long as the main drive gear turns freely. Reattach the drive assembly to the control valve and connect all plugs. After completing any valve maintenance, press and hold NEXT and REGEN buttons for 3 seconds or unplug power source jack (black wire) and plug back in. This resets the electronics and establishes the service piston position. The display should flash all wording, then flash the software version (e.g. 181) and then reset the valve to the service position.



Spacer Stack Assembly:

To access the spacer stack assembly remove the drive assembly, drive cap assembly and piston. The spacer stack assembly can be removed easily without tools by using thumb and forefinger. Inspect the black o-rings and clear lip seals for wear or damage. Replace the entire stack if necessary. Do not disassemble.

The spacer stack assembly may be chemically cleaned (dilute sodium bisulfite or vinegar) or wiped with a soft cloth.

The spacer stack assembly can be pushed in to the control valve body bore by hand. Since the spacer stack assembly can be compressed it is easier to use a blunt object (5/8" to 1-1/8" in diameter) to push the center of the assembly into the control valve body. The assembly is properly seated with at least four threads are exposed (approximately 5/8"). Do not force the spacer stack assembly in. The control valve body bore interior can be lubricated with silicone to allow for easy insertion of the entire stack. Do not use silicone or any other type of lubricant on the clear lip seals or the piston.

Reattach the drive cap assembly and piston(s) and the drive assembly.

After completing any valve maintenance, press and hold NEXT and REGEN buttons for 3 seconds or unplug power source jack (black wire) and plug back in. This resets the electronics and establishes the service piston position. The display should flash all wording, then flash the software version (e.g. 181) and then reset the valve to the service position.

Injector Cap, Screen, Injector Plug and Injector:

Unscrew the injector cap and lift off. Loosen cap with special plastic wrench or pliers if necessary. Attached to the injector cap is a screen. Remove the screen and clean if fouled. The plug and/or injector can be pried out with a small screwdriver. The plug can be wiped clean. If the plug leaks replace the entire plug. The injector consists of a throat and a nozzle. Chemically clean the injector with vinegar or sodium bisulfite. The holes can be blown out with air. Both pieces have a small diameter holes that control the flow rates of water to insure that the proper concentration of regenerant is used. Sharp objects, which can score the plastic, should not be used to clean the injector. Scoring the injector or increasing the diameter of the hole could change the operating parameters of the injector. Push the plug(s) and/or injectors firmly in place, replace the screen and hand tighten the injector cap.

Refill Flow Control Assembly or Refill Port Plug:

To clean or replace the refill flow control, pull out the elbow-locking clip and then pull straight up on the elbow. Replace the elbow locking clip in the slot so that it is not misplaced. Twist to remove the white flow control retainer. The flow control can be removed by prying upward through the side slots of the retainer with a small flat blade screwdriver.

Clean the flow control or the white flow control retainer using dilute sodium bisulfite or vinegar. Do not use a wire brush. If necessary, replace the flow control, o-ring on the flow control retainer, or the o-ring on the elbow.

Reseat the flow control so the rounded end is visible in the flow control. Reseat the white flow control retainer by pushing the retainer into the elbow until the o-ring seats. Remove locking clip, push down on elbow to reseat and insert locking clip. Do not use petroleum jellies, oils, or other unacceptable on o-rings. A silicone lubricant may be used on the o-ring on the elbow or the white retainer.

Water Meter or Meter Plug:

The water meter assembly is connected to the PC board by a wire. If the entire water meter assembly is to be replaced, remove the control valve cover and disconnect the power source and water meter plugs from the PC Board. Unlatch the drive assembly and lean it forward. Unthread the water meter wire from the side of the drive assembly and through the drive back plate. To reinstall, rethread the water meter wire through the drive back plate and the side of the drive assembly. Reattach the drive assembly and the water meter and power plugs. If no water meter wire is visible, then a plug is installed, not a water meter. The water meter wire does not need to be removed from the PC board if the water meter is only being inspected and cleaned. To remove the water meter assembly, unscrew the meter cap on

the left side of the control valve. Pliers may be used to unscrew the nut if necessary. With the nut removed, a slot at the top of the water meter is visible. Twist a flat blade screwdriver in the slot between the control valve body and the meter. When the meter is part way out it is easy to remove the water meter from the housing. Once the water meter is removed from the control valve body, gently pull forward on the turbine to remove it from the shaft.

Do not use a wire brush to clean the turbine. Wipe with a clean cloth or clean in dilute sodium bisulfite or vinegar. The turbine can be immersed in the chemical. Do not immerse electronics. If the turbine is scored or damaged or the bearing on the turbine are worn, replace the turbine.

Do not lubricate the turbine shaft. The turbine shaft bearings are prelubricated. Do not use petroleum jellies, oils, or other unacceptable lubricants on the o-ring. A silicone lubricant may be used on the black o-ring.

Snap the turbine on the shaft and reinsert the water meter into the side slot. Hand tighten the nut. Do not use a pipe wrench to tighten nut.

Bypass Valve:

The working parts of the bypass valve are the rotor assemblies that are contained under the bypass valve caps. Before working on the rotors, make sure the system is depressurized. Turn the red arrow shaped handles towards the center of the bypass valve and back several times to ensure rotor is turning freely.

The nuts and caps are designed to be unscrewed or tightened by hand. If necessary a pliers can be used to unscrew the nut or cap. Do not use a pipe wrench to tighten or loosen nuts or caps. Do not place screwdriver in slots on caps and/or tap with a hammer. To access the rotor, unscrew the cap and lift the cap, rotor and handle out as one unit. Twisting the unit as you pull it out will help to remove it more easily. There are three o-rings: one under the rotor cap, one on the rotor stem and the rotor seal. Replace worn o-rings. Clean rotor. Reinstall rotor.

When reinstalling the red arrow handles be sure that:

1. The handle pointers are lined up with the control valve body arrows, and the rotor seal o-ring and the retainer on both rotors face to the right when being viewed from the front of the control valve; or
2. Arrows point toward each other in the bypass position.

Since the handles can be pulled off, they could be accidentally reinstalled 180° from their correct orientation. To install the red arrow handles correctly, keep the handles pointed in the same direction as the arrows engraved on the control valve body while tightening the bypass valve caps. After completing and valve maintenance, press and hold NEXT and REGEN buttons for 3 seconds or unplug power source jack (black wire) and plug back in. This resets the electronics and establishes the service piston position. The display should flash all wording, then flash the software version (e.g. 181) and then reset the valve to the service position.

SECTION 5: SYSTEM TROUBLESHOOTING GUIDE

Problem	Cause	Solution
1. Hard water (unit not using salt; liquid level in brine tank NOT too high)	A. Electrical service to unit interrupted	A. Assure permanent electrical service (check fuse, plug, pull chain, or switch)
	B. Timer not working.	B. Replace timer assembly.
	C. Timer improperly set	C. Check programming function
	D. Safety brine valve not opening	D. Replace safety brine valve
	E. Salt "bridged" in brine tank	E. Breakup salt
	F. Meter not functioning	F. Clean or replace as necessary
2. Hard water (unit using salt; liquid level in brine tank NOT too high)	A. Bypass open	A. Close bypass (replace if necessary)
	B. Timer improperly set	B. Increase frequency of regeneration
	C. No salt in brine tank	C. Add salt; maintain above water level
	D. Excessive water usage	D. Increase frequency of regeneration and/or salt setting (See HOW TO SET TIMER)
	E. Unit installed backwards	E. Reinstall unit
	F. Unit undersized	F. Replace with larger unit
3. Liquid level in brine tank TOO high	A. Brine valve not closing	A. Replace brine valve
	B. Salt setting too high	B. Reset timer
	C. Injector or Injector screen plugged	C. Clean injector and screen
	D. Drain line frozen, plugged or restricted	D. Free drain
	E. Salt "mushed" or sand from salt plugging bottom of brine tank	E. Clean out brine tank (see instructions)
	F. Incorrect brine line flow control (BLFC)	F. Replace with correct flow control (see specifications)
4. System regenerates at wrong time of day	A. Timer improperly set	A. Reset timer
5. Water continuously flows to drain	A. Foreign material in control valve	A. Remove piston assembly and inspect bore: remove foreign material and check control in various regeneration positions
	B. Internal control leak	B. Replace seals and/or piston assembly
	C. Control valve jammed in brine or backwash position	C. Replace piston, seals and spacers
6. Water tastes salty	A. Salt setting too high	A. Reset program cycle
	B. Cyclone distributor tube too short	B. Replace
7. White spots on glassware and dark surfaces	A. Sodium residual resulting from water having very high hardness or total dissolved solids (TDS)	A. Installation of additional water treatment equipment such as reverse osmosis or demineralization
8. Low water pressure (low flow rate)	A. Iron build-up in line to water conditioner	A. Clean line to water conditioner
	B. Iron build-up in water conditioner	B. Clean control and add Iron-X Mineral Cleaner to resin bed: increase frequency of regeneration
	C. Well pumping sand	C. Install sand trap
	D. Pump losing capacity	D. Contact pump repair service
9. "Rotten egg" smell (from hot water only)	A. Magnesium rod in water heater	A. Replace with aluminum rod or remove
10. "Rotten egg" smell (from both hot and cold water)	A. Hydrogen sulfide ("sulfur") in water supply	A. Install Sul-X Sulfur Reduction System
	B. Bacterial iron in water supply	B. Install Chem-Free Iron Reduction System
	C. Algae in water supply	C. Pour approximately 1/2 cup laundry bleach into brine well just before regeneration as frequently as necessary
11 Loss of resin through drain	A. Air in water system	A. Assure that well system has proper air eliminator control: check for dry well condition

SECTION 6: SPECIFICATIONS AND OPERATING DATA

ITEM	CFSM1254
Nominal Media Vol.	
Ft ³ High Capacity Cation Exchange Media	2.5
Salt Dosage, Lbs.	
Factory Setting	24
Softening Capacity, Grains	
At Factory Salt Setting	62,200
Flow Rates	
Continuous (no duration limit)	9
Service Flow Rate	10
At 15 psi Pressure Loss	11.9
Pressure Loss, psi	
At Continuous Flow	10
Service Flow Rate	12
Regeneration Flow Rates, gpm	
Backwash	3.2
Brine Draw	0.56
Slow Rinse	3.2
Rapid Rinse	3.2
Brine Refill	0.5
Approximate Water Used (at Factory Setting)	140
Regeneration Cycle Duration (approximate minutes)	
Backwash	8
Brine Draw / Slow Rinse	60
Rapid Rinse	10
Settling Rinse	8
Brine Refill (At Factory Setting)	10
Regeneration Duration Complete (approximate hours)	3
Inlet/Outlet size	
Inches	1"
Mineral Tank Size	
Tank Dia. x Ht., In.	12 x 54
Overall D & H w/ Valve, Inches	
Width (Including Brine Tank)	58
Depth (Including Meter and Bypass)	17
Height (Including Valve)	62
Brine Tank Size	
W x D x H, Inches	15 x 15 x 34
Brine Tank Capacity	
With Salt Grid Leg Extensions (required on salt settings above 18#)	135
Miscellaneous	
Approximate Shipping Weight (lbs)	188
Maximum Operating Temperature	100°F (38°C)
Minimum Operating Temperature	34°F (1°C)
Operating Pressure	20-100 psi (138-689 kPa)
Electrical Requirements	110/120v, 60 Hz


NOTES:

- 1) The CFSM1254E softener conforms to NSF/ANSI Standard 44 for specific performance claims as verified and substantiated by test data. Actual capacity may vary substantially depending on water analysis and operating conditions.
- 2) For satisfactory performance listed flow rate and duration should not be exceeded. Flow rates listed are adequate for normal applications.
- 3) The CFSM1254E softener is not intended to be used for treating water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- 4) All types of water softener salt may be used (see Maintenance.)

Section 7: PARTS COMPONENT PARTS LIST

REF No.	DESCRIPTION	CFSM1254
1	Control Valve	W12M320-5B3-0M
2	Adapter Assembly, Flange-Thread (Incl. Ref 3)	FA45TX
3	O-Ring	ORG-234
4	Clamp Assembly (Incl. Ref 3)	FC45XX
5	Media Tank (Incl. Ref 9)	MTP1254FB
6	Media	H-10P(x2) & H-050
7	CYCLONE Assembly	C04N-54
8	Tank Base	T06A-12P
9	Brine Line Tubing	13000X
10	Brine Tank, Complete, Black	BT1534X-EXT-DLS
11	Overflow Fitting	BT16
12	Brine Tank Shell, Black	BT1534
13	Brine Well w/ Cap	BT15BW
14	Grid Plate w/Extension Kit	BT15GP-EXT
15	Safety Brine Valve, Complete	BT15SBVA
16	Safety Brine Valve	60014
17	Float Assembly	60068X
18	Air Check Assembly	60002
19	Salt Monitor	TPCB-TB30D
20	Brine Tank Lid	BT15L

NOTE: When ordering replacement or repair components always specify by the unit or model number to ensure correct parts delivered.




Items Not Shown	
Description of Item	Part Number
Wrench	V3193-01
Universal Elbow	V3191-01
Retaining Clip	H4615
Drain Line Insert	PKP10TS8-BULK
Drain Line Elbow Nut	V3192
Drain Line Elbow	3158-01
Plumbing Adapter Kits	
1" Brass Sweat	V3007-02
1" Plastic Male NPT	V3007-04
1.25" Plastic Male NPT	V3007-05
1" Plastic Male BSP	V3007-06

Section 7: PARTS COMPONENT PARTS LIST

Front Cover and Drive Assembly

Drawing No.	Order No.	Description	Quantity
1	V1375-01	WS1 Front Cover	1
2	V3107-01	WS1 Motor	1
3	V3106-01	WS-1 Drive Bracket & Spring Clip	1
4	V3108	WS1 PC Board	1
	V3002	WS1 Drive Assy*	1
Not Shown	V3168	WS1 AS Adapter 110V-12 V	1
Not Shown	V3168-01	WS1 AC Adapter Cord Only	1


* Drawing number parts 2 through 6 may be purchased as a complete assembly, part V3002.



Section 7: PARTS COMPONENT PARTS LIST

Drive Cap Assembly, Downflow Piston, Regenerant Piston and Spacer Stack Assembly

Drawing No.	Order No.	Description	Quantity
1	V3005	Spacer Stack Assembly	1
2	V3004	Drive Cap Assembly	1
3	V3178	Drive Back Plate	1
4	V3011	Piston Down Flow Assembly	1
5	V3174	Regenerant Piston	1
6	V3135	O-ring 228	1
7	V3180	O-ring 337	1
8	V3105	O-ring 215 (Distributor Tube)	1
Not Shown	V3001	Body Assembly	1




Section 7: PARTS COMPONENT PARTS LIST

Injector Cap, Injector Screen, Injector, Plug and O-Ring

Drawing No.	Order No.	Description	Quantity
1	V3176	Injector Cap	1
2	V3152	O-ring 135	1
3	V3177	Injector Screen	1
4	V3010-1Z	Injector Assy. Z Plug	1
5	V3010-1F	INJECTOR ASSY H BLUE	
Not Shown	V3170	O-ring 011	*
Not Shown	V3171	O-ring 013	*

* The injector plug and the injector each contain one 011 (lower and 013 (upper) o-ring



Section 7: PARTS


COMPONENT PARTS LIST

Refill Flow Control Assembly

Drawing No.	Order No.	Description	Quantity
1	H4615	Elbow Locking clip	1
2	JCP-P-6	Polytube insert 3/8"	1
3	JCPG-6PBLK	Nut 3/8"	1
4	H4613	Elbow Cap 3/8"	1
5	V3163	O-ring 019	1
6	V3165-01*	BLFC Retainer Assembly**	1
7	V3182	BLFC	1
Not Shown	H4650	Elbow 1/2" with nut and insert	Option

* Assembly includes V3182 BLFC.


** Includes drawing #7.



Section 7: PARTS COMPONENT PARTS LIST


Drain Line - 3/4"

Drawing No.	Order No.	Description	Quantity
1	H4615	Elbow Locking Clip	1
2	PKP10TS8-BULK	Polytube insert 5/8	1
3	V3192	Nut 3/4 Drain Elbow	1
4	V3158-01	Drain Elbow 3/4 Male	1
5	V3163	O-ring 019	1
6	V3159-01	DLFC Retainer Assembly	1
7	V3162-032	DLFC 3.2 gpm for 3/4"	One DLFC must be used if 3/4 fitting is used



Section 7: PARTS **COMPONENT PARTS LIST** **Water Meter and Meter Plug**


Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" QC	1
2	V3003	Meter Assembly (includes drawing #3 & #4)	1
3	V3118-01	Turbine	1
4	V3105	O-ring 215	1
5	V3003-01	Meter Plug Assembly	1



Section 7: PARTS COMPONENT PARTS LIST


Order No: V3007-02
Description: Fitting 1" Brass Sweat Assembly

Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" Quick Connect	1
2	V3150	Split Ring	1
3	V3105	O-ring 215	1
4	V3188	Fitting 1" Brass Sweat Assembly	1




Order No: V3007-03
Description: Fitting 3/4" Brass Sweat Assembly

Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" Quick Connect	1
2	V3150	Split Ring	1
3	V3105	O-ring 215	1
4	V3	Fitting 3/4" Brass Sweat Assembly	1




Order No: V3007-04
Description: Fitting 1" Plastic Male NPT Assembly

Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" Quick Connect	1
2	V3150	Split Ring	1
3	V3105	O-ring 215	1
4	V3164	Fitting 1" Plastic Male NPT	1



Order No: V3007-05
Description: Fitting 1-1/4" Plastic Male NPT Assembly

Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" Quick Connect	1
2	V3150	Split Ring	1
3	V3105	O-ring 215	1
4	V3317	Fitting 1-1/4" Plastic Male NPT	1




Section 7: PARTS COMPONENT PARTS LIST

Bypass Valve

Drawing No.	Order No.	Description	Quantity
1	V3151	Nut 1" Quick Connect	2
2	V3150	Split Ring	2
3	V3105	O-ring 215	2
4	V3145	Bypass 1" Rotor	2
5	V3146	Bypass Cap	2
6	V3147	Bypass Handle	2
7	V3148	Bypass Rotor Seal Retainer	2
8	V3152	O-ring 135	2
9	V3155	O-ring 112	2
10	V3156	O-ring 214	2

V3191-01 Vertical Adapter Assembly

Order No.	Description	Quantity
V3151	Nut 1" Quick Connect	2
V3150	Split Ring	2
V3105	O-ring 215	2
V3191	Vertical Adapter	2




Section 7: PARTS

COMPONENT PARTS LIST

Wrench

(Order No. V3193-01)

Although no tools are necessary to assembly or disassemble the valve, the wrench (shown in various positions on the valve) may be purchased to aid in assembly or disassembly.



LIMITED WARRANTY

For any warranty questions, please refer to the enclosed warranty card or call 1-800-222-7880 or mail your request to:

CUNO Incorporated
400 Research Parkway
Meriden, CT 06450

